



Planter Bed Sprays-To-Drip Retrofit (PBSD-Retro1800)

Photo	Model	Description	Quantity	Reorder
	Rain Bird Products			
	XFS-06-12-100	XFS Sub-Surface Dripline 0.6 gph 12" spacing with Copper Shield Technology	2	
 XF Insert Fittings Model: XFF-COMBOPK 	XFF-COMBOPK	XFF Combo Pack	2	
	<i>Includes:</i> 	5 XFF-TEE 17 mm barb tee	0	
		2 XFF-Elbow 17 mm elbow	0	
		5 XFF-Coup 17 mm barb Coupling	0	
		1 FITINSTOOL Insertion Tool	0	
	XFF-TMA-050	XFF Tee Male Adapter	1	
	XFF-MA-050	1/2" MPT x 17 MM	1	
		1/2" Schedule 40 Threaded Coupler (gray)	1	
	TDS-050BEND	Galvanized Tie Down Stakes	40	
	RETRO-1800	1800 Retrofit Kit with 200 mesh filter and 30 psi regulator	1	
	XC-1800	Xeri-Caps for 1800 spray bodies	10	
	MDCF-COUP	Flush Valve-Component 1	2	
	MDCF-CAP	Flush valve-Component 2	2	
	PPC200X	Tubing Cutters	1	
	XFD-100	17 mm XFD Blank Tubing 100-foot (brown)	1	
		1/2" PVC Threaded cap	10	
Required for Sub-Surface: Air Relief Valve Assembly and Flush Valve Assembly				
	ARV-050	Rain Bird Air Relief Valve	1	
		Schedule 40 Coupler (Gray)	1	
	XFF-TMA-050	17mm x 1/2" MPT	1	
	SEB-7XB	Subterranean Emitter Box	2	